



.:Kicker ball replacement:.

**1. Spare set**



**2. Mark the middle of the arm**





.:Kicker ball replacement:.

**3. Drill a hole in the middle of arm.**



**4. If there is a screw in the middle of the ball between other 3 screws, unscrew the middle one.**

**5. Place the ball into the arm.**





.:Kicker ball replacement:.

**6. Prepare screw from spare set (or the one you unscrew in point 4).**



**7. Screw in prepared screw into the middle hole.**





.:Kicker ball replacement:.

**8. Use spanner no 13.**



**9. Screw in from the outside of the arm.**





.:Kicker ball replacement:.

**10. Screw in so far that the 3 ball screws can be seen outside the arm.**



**11. Using spanner 13 screw in 3 screws from the ball.**





.:Kicker ball replacement:.

12. **IMPORTANT!** Take out screw from the middle of the arm.



13. Job done. New ball is ready.



**REMEMBER:** After first 300 kicks tighten the screws. Then repeat tightening every 500 kicks so they do not get loose.